



















INSTRUCTION MANUAL



FM ANTENNA

REMOTE CONTROL



SPEAKER BOX CORNER x2



High Energy Entertainment Center 10,000 Watts PMPO Bluetooth LED Illuminated Speaker DJ Dual System A/B Player

Party System 6000





## PS6000

- 10,000 Watts PMPO
- Twin 15" Woofers & (2) 1.5" Tweeters
- LED Illuminated Speaker
- Bluetooth Wireless Pairing
- Play DVD, CD, USB, SD, Aux In or FM
- LED VFD Display
- Equalizer and Fader
- Remote Control
- Microphone Input
- (microphone not included)
- DJ Dual System Player A / B
   Bluetooth (2), Karaoke (2),
   USB (2), SD (2), FM (2),
   LED VFD Display (2)

























- DJ Dual A/B System Player Top of Receiver ----
- Back of Receiver



#### FRONT PANEL-CONTROLS AND FUNCTIONS



BT(EDISON 5000A) /USB /SD /Karaoke /Fm radio /VFD display

- 1.Power ON/OFF
- 2. Mute of whole unit
- 3.AB System fader
- 4.AB Equalizer
- 5.AB Equalizer
- 6.AB Equalizer
- 7.AB Equalizer
- 8.A System Volume control knob
- 9.A System ECHO decrease
- 10.A System ECHO increase
- 11.A System Microphone volume decrease key 12.A System Microphone volume increase key
- 13.A System Previous key
- 14.A System Play/Pause/Mute key
- 15.A System Next key
- 16.A System DSP decrease key
- 17.A System BT input key
- (BT searching name: EDISON 5000A)

- 18.A System AUX input key
- 19.A System FM input key
- 20.A System USB/SD card input key
- 21.A System DSP increase key
- 22.A System play again key
- 23.A System Treble decrease key
- 24.A System Treble increase key
- 25.A System BASS decrease key
- 26.A System BASS increase key 27.A System MUTE key
- 28.A System BASS increase/decrease
- 29.A System MID increase/decrease
- 30.A System Treble increase/decrease

### 33.B System ECHO increase 34.B System Microphone volume decrease key

FRONT PANEL-CONTROLS AND FUNCTIONS

A B SYSTEM EQUALIZER

35.B System Microphone volume increase key 36.B System Previous key

32.B System ECHO decrease

31.B System Volume control knob

- 37.B System Play/Pause key
- 38.B System Next key
- 39. Amplifier LED switch ON/OFF
- 40.B System BT input key
- (BT searching name: EDISON 5000B)
- 41.B System AUX input key
- 42.B System FM input key 43.B System Language select key

- Built-in DVD /BT(EDISON 5000B) /USB /SD /Karaoke /Fm radio /VFD display /Full function remote
  - 44.B System DVD input key 45.B System DVD/USB/SD input key

  - 46.B System Mute key
  - 47.B System Treble decrease key 48.B System Treble increase key
  - 49.B System BASS decrease key
  - 50.B System BASS increase key
  - 51.B System DVD open/close key
  - 52.B System Treble increase/decrease 53.B System MID increase/decrease
  - 54.B System BASS increase/decrease





PS6000

## Speaker (x2)

- Unit Dimensions
  16.0" W x 20.0" L x 48.3" H
- Unit Weight 66.2lbs.

## Receiver

- Unit Dimensions
  15.0" W x 20.9" L x 11.1" H
- Unit Weight 26.7lbs.











# Accessories




SPEAKER CABLE x2



VIDEO CABLE



REMOTE CONTROL



INSTRUCTION MANUAL



**FM ANTENNA** 



AUDIO CABLE



**BANANA PLUGS** 



SPEAKER BOX CORNER x2





## PS6000

- Receiver
- Carton Dimensions
  15.0" W x 20.9" L x 11.1" H
- Carton Weight 26.7lbs.
- Pallet Quantity 36pcs.
- Ti Hi: x x x
- Carton Cube (cu/ft) x.x CBM
- Container Quantity:

20'GP pcs, 40'HQ pcs, XXXpcs 45'HQ pcs.









## PS6000

- Speaker (x2)
- Carton Dimensions
  16.0" W x 20.0" L x 50.2" H
- Carton Weight 66.2lbs.
- Pallet Quantity 10pcs.
- Ti Hi: x x x
- Carton Cube (cu/ft) x.x CBM
- Container Quantity:

20'GP pcs, 40'HQ pcs, XXXpcs 45'HQ pcs.



